



Bio-Therapeutic
Skin Care for life inside and out®



bt-vision® 2.0

Instruction Manual

Thank you for purchasing the bt-vision® 2.0
Please read instructions carefully before using.

Care

- To clean the lenses, wipe gently with a damp soft cloth or an alcohol wipe. Avoid using chemical detergents, as they will deteriorate the surface of lens.
- To clean the plastic and silicone components, wipe gently with a damp soft cloth or an alcohol wipe. Avoid using chemical detergents, as they may deteriorate the plastic.
- **NOTE:** Do not immerse unit in water.

Battery

Battery compartment is located on inside of visor, behind blue azul forehead pad. Open battery cover by gently pressing white tab away from inner visor.

Ensure that battery compartment ribbon is placed beneath the batteries. Insert 3 AAA batteries in battery compartment, ensuring correct polarity position.

Replace battery compartment cover by installing bottom first and then gently pressing top tab in until it clicks.

Always use high quality batteries for best results (Type AAA).

Lenses

NOTE: Take care not to drop or scratch the lenses.

5 magnification lenses: 1X, 1.5X, 2.0X, 2.5X, 3.5X

Choose and install preferred lens by gently pushing lens into insertion clasp located under the light assembly.

Lens should be inserted with flat side towards eyes.

Adjust for best vision. Align lens directly in front of eyes.

Avoid fingerprints on the lens. When handling, use soft tissue paper or protective paper.

Wearing

Wear bt-vision by placing arms over ears.

For use with glasses, wear with bt-vision bridge in front of glasses.

For extended wear, or as preferred comfort option, attach headband.

1. Remove arms by pressing button where visor meets arm and pulling apart. Store arms in a safe place to avoid loss.
2. Attach headband strap by replacing each arm with end of headband. Push into place until fully inserted. A “click” will sound.

Light

Turn light on by sliding blue light switch forward. Light switch is located on top of light assembly.

Turn off by sliding switch towards forehead.

Adjustments

Lens angle: Lift up to move lens away. Bring down to use lens.

Adjust lens slot by grasping lens slot with finger and thumb on either side and moving front or back.

Adjust the light at top of light assembly by inserting thumb under the rear side of light.

Lift light by grasping side and gently lifting up or down.

Features and specifications

Dimensions: 9.5" x 5.75" x 3.75"

Weight: 4.2 oz (with batteries and lens)

Lens weight: .45 - .8 oz

Headband weight: .35 oz

Power: 3 AAA batteries

Silver Ion Technology: forehead rest, nose rest, ear rest

Clear LED illumination system

Light swivels 45°

5 magnification lenses: 1X, 1.5X, 2.0X, 2.5X, 3.5X

Quick release lens system

Antibacterial and antimicrobial silicone surfaces

Includes detachable elastic headband option

Completely adjustable for optimum comfort and all day wear

1 year warranty

Caution:

- Do not view direct sunshine through the lens.
- Do not place lens between direct sunlight and any combustible material.
- Keep out of reach of children.
- Do not immerse in water.

Bio-Therapeutic / Micro Current Technology, Inc.

2244 1st Ave S. Seattle, WA 98134

